

## VGA BIOS UPDATE PROCESS

Note1: Not all BIOS updates are necessary or required.


Note2: The BIOS update process is completely automated once it is started. The whole process may require up to 10 mins.

Note3: Your system will be restarted upon BIOS update completion. Ensure to close all running applications before starting update process.

1. Check your VGA model's current BIOS
  - a. Run FireStorm. For the latest download go here - <https://www.zotac.com/page/firestorm>
  - b. Click on Settings (gear icon on upper right corner)



- c. Click on Information



- d. Note down the BIOS version



- e. Close and exit FireStorm
  2. Download the BIOS update file
  3. Extract the BIOS update file
  4. There should be one executable file (.exe)
  5. At this point, we are ready to begin the BIOS update process. CAUTION: Please close all applications from this point on.
  6. Double click on the BIOS update file to begin the BIOS update process.
- Note: All processes are automated and will require no interaction during the update process.

```
NVIDIA Firmware Update Utility
Version 5.560.0
Copyright (C) 2018-2019, NVIDIA Corporation. All rights reserved.
```

```
The display may go *BLANK* on and off for up to 6 seconds
or more during access to the EEPROM depending on your display
adapter and output device, it will begin in about 3 seconds.
```

```
or more during access to the EEPROM depending on your display
adapter and output device, it will begin in about 3 seconds.
```

```
Firmware Image Version: 90.04.76.40.FB
Found display adapter suitable for this update:
GeForce RTX 2070 SUPER Device Path: S:00,B:01,D:00,F:00
Current Firmware Version: 90.04.76.00.B7
```

```
UPDATE WILL BEGIN IN ABOUT 3 SECONDS.
```

```
[=====] 71 %
```

7. Once the update process is complete, the system will restart.
8. End process.