




GO TO +

ZOTAC-CUP.COM



WORIGINAL HMINI PC







vimeo.com/zotac





USER'S MANUAL



ZOTAC ZBOX User's Manual



No part of this manual, including the products and software described in it, may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form or by any means, except documentation kept by the purchaser for backup purposes, without the express written permission of ZOTAC.

Products and corporate names mentioned in this manual may not be registered trademarks or copyrights of their respective companies, and are used for identification purposes only. All trademarks are the property of their respective owners.

Every effort has been made to ensure that the contents of this manual are correct and up to date. However, the manufacturer makes no guarantee regarding the accuracy of its contents, and reserves the right to make changes without prior notice.

CAUTION:

Risk of explosion if the battery is replaced with an incorrect type. Batteries should be recycled where possible. Disposal of used batteries must be in accordance with local environmental regulations.

Table of Contents

Product specifications	3
Safety information	4
Setting up your system	4
Care during use	4
Welcome	
Package contents	5
Getting to know your ZOTAC ZBOX	6
Front view	
Rear view	7
How to disable the ring LED indicator	
Installing hardware inside the ZOTAC ZBOX	10
Installing a memory module	11
Removing a memory module	12
Installing a hard disk drive	13
Setting up your ZOTAC ZBOX	
Positioning your ZOTAC ZBOX	16
Installing the stand	
Attaching your ZOTAC ZBOX to a display	16
Installing drivers and software	
Installing an operating system	
Installing system drivers	17
Using your ZOTAC ZBOX	18
Configuring a wireless connection	18
Configuring a wired connection	
Using a static IP	
Using a dynamic IP (PPPoE connection)	19
Configuring audio output	20

Product specifications

- Microprocessor support
 - ❖ Intel Core i3-7100U (dual core 2.4 GHz) for ZBOX MI526
 - ♦ Intel Core i5-7200U (dual core 2.5 GHz, up to 3.1 GHz) for ZBOX MI548
- □ Operating systems:
 - ❖ Windows 10 64-bit
- □ System Memory support
 - * Two 260-pin SO-DIMMs DDR4 up to 2133 Mbps
 - ❖ Up to 32 GB of memory
- □ USB Ports
 - * Two USB 3.1 Type-C port, one USB 3.0 port (from SD/USB 3.0 Combo) at front panel
 - ❖ Two USB 3.0 ports and one USB 2.0 port at rear panel, one USB 3.0 port at top panel
- Onboard Serial ATA
 - ❖ SATA 6.0 Gb/s transfer rates
 - ❖ Supports one 2.5-inch SATA HDD or SSD (max 9.5mm height)
- □ Onboard Dual LAN
 - ❖ Supports 10/100/1000 Mbps operation
 - ❖ Supports IEEE 802.3
- □ WiFi/Bluetooth support
 - ❖ 802.11ac (dual-band), n/g/b
 - ❖ Bluetooth v4.2
- □ Onboard Audio
 - Stereo analog audio output and Microphone input
- Onboard Graphics support
 - ❖ Intel HD Graphics 620
 - ❖ DP1.2 (max resolution: 3840x2160 @60Hz)
 - HDMI1.4 (max resolution: 3840x2160 @30Hz)
- □ Product Size
 - ❖ 188mm x 188mm x 44mm

Safety information

Your ZOTAC ZBOX is designed and tested to meet the latest standards of safety for information technology equipment. However, to ensure your safety, it is important that you read the following safety instructions.

Setting up your system

- Read and follow all instructions in the documentation before operating your system.
- Do not use this product near water or a heat source such as a radiator.
- Set up the system on a stable surface with the provided stand. Never use the system alone without the stand.
- Openings on the chassis are for ventilation. Do not block or cover these openings. Make sure you leave plenty of space around the system for ventilation. Never insert objects of any kind into the ventilation openings.
- ❖ Use this product in environments with ambient temperatures between 0°C and 35°C.
- If you use an extension cord, please use the UL listed cord and make sure that the total ampere rating of the devices plugged into the extension cord does not exceed its ampere rating.

Care during use

- . Do not walk on the power cord or allow anything to rest on it.
- Do not spill water or any other liquids on your system.
- When the system is turned off, a small amount of electrical current still flows. Always unplug all power, modem, and network cables from the power outlets before cleaning the system.
- If you encounter the following technical problems with the product, unplug the power cord and contact a qualified service technician or your retailer.
 - > The power cord or plug is damaged.
 - > Liquid has been spilled into the system.
 - > The system does not function properly even if you follow the operating instructions.
 - > The system was dropped or the cabinet is damaged.
 - > The system performance changes.

Welcome

Congratulations on your purchase of the ZOTAC ZBOX. The following illustration displays the package contents of your new ZOTAC ZBOX. If any of the below items is damaged or missing, contact your retailer.

Package contents

- 1 x ZOTAC ZBOX
- 1 x Stand
- 1 x VFSA mount
- 1 x AC Adapter
- 1 x Power Cord
- 1 x Antenna
- 1 x Support DVD
- · 1 x USB flash drive with OS drivers
- 1 x User Manual & Quick Start Guide
- · 1 x Warranty Card



Getting to know your ZOTAC ZBOX Front view



Refer to the diagram below to identify the components on the front of the ZBOX

1. Headphone/Audio Out jack

The stereo headphone jack (3.5mm) is used to connect the system's audio output signal to amplified speakers or headphones.

2. Microphone jack

The microphone jack is designed to connect a microphone for video conferencing, voice narrations or simple audio recordings.

3. Combo USB 3.0 port / Memory card slot

The Combo USB 3.0 port / Memory card slot is compatible with USB 3.0 devices or SD/SDHC/SDXC cards used in devices like digital cameras, MP3 players, mobile phones and PDAs.

4. USB 3.1 Type-C ports

The type-C USB 3.1 port supports the SuperSpeed USB 3.1 devices. Use this port for USB 3.1 devices for maximum performance with USB 3.1 compatible devices.

5. Wi-Fi status indicator

The Wi-Fi LED is always ON when data is being transfered over Wi-Fi.

6. Hard disk LED

The hard disk LED blinks when data is being written onto or read from the hard disk drive.

7. Power switch

The power switch allows powering ON and OFF the system.

Rear view



Refer to the diagram below to identify the components on the back of the system.

1. WiFi antenna connector

The WiFi antenna connector supports the included WiFi antenna.

2. DisplayPort

DisplayPort supports both external (box-to-box) and internal (laptop LCD panel) display connections.

3. Ethernet ports

The eight-pin RJ-45 LAN port supports standard Ethernet cable for connections to local area networks (LAN) with speeds of 10/100/1000Mbps.

4. USB 2.0 port

The USB (Universal Serial Bus) port is compatible with USB devices such as keyboards, mice, cameras and hard disk drives.

5. HDMI port

The HDMI (High Definition Multimedia Interface) port supports a UHD device such as an LCD TV or monitor to allow viewing on a larger external display.

6. USB 3.0 ports

The USB 3.0 port supports the SuperSpeed USB 3.0 devices and is backwards compatible with USB 2.0/1.1 devices. Use this port for USB 3.0 devices for maximum performance with USB 3.0 compatible devices.


7. Power input (DC19V)

The supplied power adapter converts AC power to DC power for use with this jack. Power supplied through this jack supplies power to the PC. To prevent damage to the PC, always use the supplied power adapter.


The power adapter may become warm to hot when in use. Do not cover the adapter and keep it away from your body.

How to disable the ring LED indicator

- 1. Turn on the ZBOX Mini PC and press < Delete > to enter the BIOS SETUP UTILITY.
- 2. Use the arrow keys to navigate to the **Power** menu and select **Logo Indicator**.



Press <Enter> and select Turn off.



4. Press F10 to save the configuration and exit.

Installing hardware inside the ZOTAC ZBOX

Before installing hardware, please follow the instructions below to remove the cover of your ZOTAC ZBOX.

1. Remove the two rear thumb screws.



2. Gently remove the cover as shown below.



Installing a memory module

 Locate the SO-DIMM memory slots and insert a SO-DIMM memory module into the slot at a 45 degree angle.



Note: When installing two SO-DIMM memory modules, please insert a module into the lower slot first.


Gently press down on the memory module until it locks into place by the arms of the memory slot.



Note: This ZOTAC ZBOX accomodates two DDR4 SO-DIMM memory modules. You must install at least one module for the system to function. PLUS models include memory pre-installed.

Removing a memory module

1. Locate the SO-DIMM memory slot and gently press the two arms securing the memory module outwards, as shown in the image below, to release the memory module.



2. Remove the memory module from the slot at a 45-degree angle.



Installing a hard disk drive

 Insert the hard disk drive into the slot at a 45 degree angle and gently slide into the connector.




2. Reinstall the screw.



*PLUS models include a HDD/SSD pre-installed

Setting up your ZOTAC ZBOX

Please connect your peripherals before using your ZOTAC ZBOX.



1. Connecting the WiFi antenna

Connect the WiFi antenna to the WiFi antenna connector.

2. Connecting a DisplayPort display

Connect the DisplayPort connector to the DP port of the monitor or display.

3. Connecting to a network

Connect one end of a network cable to the LAN port on the system rear panel and the other end to a network router, hub or switch.

4. Connecting to USB 2.0 devices

Connect USB 2.0 devices such as keyboards, mice, cameras and hard disk drives.

5. Connecting to an HDMI display

Connect one end of an HDMI cable to an HDTV or monitor, and the other end to the HDMI port on the system rear panel.

6. Connecting to USB 3.0 devices

Connect USB 3.0 devices such as external hard disk drives, SSDs and flash drives to the USB 3.0 port on the system rear panel.

7. Connecting the power adapter and turning on the ZBOX

Connect the supplied AC adapter to the DC IN jack on the system rear panel and then press the power switch on the front panel to turn on the system.

When your ZOTAC ZBOX is not in use, unplug the power adapter or switch off the AC outlet to conserve power.

Positioning your ZOTAC ZBOX

- Do not position the ZOTAC ZBOX where the ventilation holes are covered. To guarantee proper use, leave 4 inches (10 cm) spacing in front of the ventilation holes.
- ZOTAC Mini PC systems provide ample connectivity in a compact form factor, please choose connectors and cables in appropriate sizes to avoid interference.

Installing the stand

Position your ZOTAC ZBOX upright with the supplied stand. To do so:

- Locate the key hole on the bottom of the ZOTAC ZBOX.
- 2. Align the stand key to the ZBOX key hole and slide the stand forward to lock into place.
- Do not place your ZOTAC ZBOX on the desktop without the stand.







Attaching your ZOTAC ZBOX to a display

You can also attach your ZOTAC ZBOX to the back of a display. To do so:

- 1. Secure the VESA mount to your display with four screws (HNM/M4x8).
- Place your ZOTAC ZBOX on the VESA mount noting the correct alignment and snap the ZBOX into place on the mount.
- To fasten the VESA mount, your display must comply with VESA75 Or VESA100 standard.
- Mechanical Loading Stability Please ensure the display rests on a stable platform before attaching ZOTAC ZBOX to prevent damage or injuries from a fall or drop.
- If the total weight of your display and ZOTAC ZBOX is over 7kg, the system may be unstable.





Installing drivers and software

Installing an operating system

The ZOTAC ZBOX does not ship with an operating system preinstalled. The user must install the operating system before the ZOTAC ZBOX can be used. The following operating systems are supported:

• Windows 10 64-bit

Follow the instructions below to install an operating system:

- 1. Attach external DVD drive via USB 3.0 or 2.0 ports.
- Note: USB 3.1 Type-C ports do not support OS installation.
- 2. Insert disk for operating system (Windows or Linux).
- 3. Wait for the ZOTAC ZBOX to boot from the disk.
- 4. Follow the onscreen directions to install the operating system.
- 5. Install system drivers to gain full functionality of the ZOTAC ZBOX hardware and features.

Installing system drivers

Before you can use the full features of the ZOTAC ZBOX, the system drivers must be installed. The following types of operating systems are supported by the ZOTAC ZBOX driver DVD and

USB flash drive:

· Windows 10 64-bit


Follow the instructions below to install the system drivers:

- Insert the ZOTAC ZBOX driver DVD or driver USB flash drive. If autorun is enabled, the driver installation main menu will show up automatically. If autorun is disabled, you may click the file Launch.EXE to bring up the driver installation main menu.
- The following drivers are available on the DVD and USB flash drive:
 - Intel Chipset Driver



- HDA Sound Driver
- · Intel Graphics Driver
- Ethernet PCI-E Driver
- Intel Ethernet PCI-E Driver
- · Wireless Network Driver
- · Intel Management Engine
- Bluetooth Driver
- · MassStorage Driver
- · Asmedia USB Controller
- USB Charger (optional)

Note: If you want to use high-amperage USB charging for smartphones and tablets, please install the driver USB Charger driver.



- 3. Select the driver you want to install. The driver installer should launch.
- 4. Follow the onscreen instructions to install the drivers.
- 5. Restart the system.

Using your ZOTAC ZBOX

Configuring a wireless connection

Please follow the instructions below to connect to a wireless network:

- 1. Double-click the wireless network icon (pic) in the notification area.
- Select the wireless network you want to connect to from the list and click Connect.
- After connection is established, you will see "Connected."
 Note 1: For security concerns, Do NOT connect to an unsecured network, otherwise, the transmitted information without encryption might be visible to others.

Note 2: Enter the network security key if necessary.





Configuring a wired connection

Using a static IP

- Right-click the network icon in the notification area and select "Open Network Connections".
- Right-click "Local Area Connection" and select "Properties".
- Highlight "Internet Protocol (TCP/IP)" and click "Properties".
- 4. Select "Use the following IP address".
- 5. Enter your IP address, subnet mask and Default gateway.
- Enter the preferred DNS server address if necessary.
- 7. After entering all of the related values, click "OK" to finish the configuration.

Using a dynamic IP (PPPoE connection)

- 1. Repeat Step 1-3 in the previous section.
- 2. Select "Obtain an IP address automatically" and click "OK".
- Click "Create a new connection" to start the NEW Connection Wizard.
- 4. Click "Next".
- Select "Connect to the Internet" and click "Next".
- Select "Set up my connection manually".
- 7. Select your connection type and click "Next".
- 8. Enter your ISP Name and click "Next".
- Enter your User name and Password. Click "Next".



- 10. Click "Finish" to finish the configuration.
- Enter your user name and password. Click "Connect" to connect to the internet.
 Note: Contact your internet Service Provider (ISP) if you have problems connecting to the network.

Configuring audio output

Follow the steps below to enable audio output when connecting the ZOTAC ZBOX to a TV or receiver via DP/HDMI adapter.

- Access the Sound settings via the system Control Panel.
- Under Playback devices, click the display device that corresponds with your audio compatible display.
- Click the "Set Default" button in the lower right hand corner.
- 4. Click "OK" to exit the setup.

