


MEK GAMING PC QUICK START GUIDE


OVERVIEW FOR MODELS: MEK5060A9600XWR1 / MEKA5060A9600XWR1

What's in the box: MEK Gaming PC, Power Cable, WiFi Antenna, Accessory Box


Top I/O Panel



Rear




Motherboard I/O Panel




1 LAN RJ-45 Port **2** Line In (Light Blue) **3** Front Speaker (Lime)
4 Microphone (Pink) **5** Antenna Ports **6** USB 3.2 Gen1 Type-A
 Ports **7** USB 2.0 Ports **8** USB 3.2 Gen2 Type-A Port **9** USB 3.2
 Gen2 Type-C Port **10** BIOS Flashback Button **11** HDMI Port
 (disabled when GPU is installed)


Power Supply



GPU Video Output Ports



STEP 1



1. Loosen and remove the 4 thumbscrews on the Tempered Glass Side Panel.
2. Carefully lift the Tempered Glass Side Panel and pull it away from the System and set it aside.
3. Carefully remove all the protective packing materials and Accessory Box from inside the system.

Re-install the Tempered Glass Side Panel and secure it with the 4 thumbscrews only after confirming the system successfully powers on and is running. Ensure the system is powered off before re-installing.

MEK GAMING PC QUICK START GUIDE

STEP 2

1. Check internal system components for Plastic Protective Film and carefully remove. The Plastic Protective Film may be found on the CPU Cooler, Case Fans, Graphics Card, and/or Chassis Tempered Glass Panels.

STEP 3

1. Connect your peripherals (KB, Mouse, Ethernet, etc.) to the **Motherboard I/O Panel**.
2. Connect the WiFi antennas to the **Motherboard I/O Panel**.
3. Connect a Monitor to a **GPU Video Output Port**.
4. Plug the power cable securely into the Power Supply.
5. Connect the power cable into an available Power Outlet.
6. Switch the Power Switch on the **Power Supply** to the (|) ON position.
7. Press the Power Button located at the **Top I/O Panel** to power on the system.

Product Registration

Register your new MEK Gaming PC on ZOTAC.COM at <https://www.zotac.com/us/support>

Technical Support

Phone: 1-877-599-6822 (Monday – Friday 9:00AM to 6:00PM PST)

Email: support.us@zotac.com

Website: <https://www.zotac.com/us/support> (Live Chat, Contact Us)